

# **E-RU.MT20.A.00434**

Ссылка на документ: <https://bazaotts.ru/otts/e-ru-mt20-a-00434>  
Файл скачан с сайта База ОТТС (<https://new.bazaotts.ru/>)



<p><b>Модель транспортного средства</b></p>	<p>АЦ 3,2-40 (MAN TGM 13.250), АЦ 3,2-40 (MAN TGM 13.280), АЦ 3,2-40 (MAN TGM 13.290), АЦ 3,2-40 (MAN TGM 18.280), АЦ 3,2-40 (MAN TGM 18.290), АЦ 3,2-40 (MAN TGM 18.330), АЦ 3,2-40 (MAN TGM 18.340), АЦ 3,2-40/4(MAN TGM 13.250), АЦ 3,2-40/4(MAN TGM 13.280) АЦ 3,2-40/4(MAN TGM 13.290), АЦ 3,2-40/4(MAN TGM 18.280) АЦ 3,2-40/4(MAN TGM 18.290), АЦ 3,2-40/4(MAN TGM 18.330) АЦ 3,2-40/4(MAN TGM 18.340) АЦ 3,2-50 (MAN TGM 13.250), АЦ 3,2-50 (MAN TGM 13.280), АЦ 3,2-50 (MAN TGM 13.290), АЦ 3,2-50 (MAN TGM 18.280), АЦ 3,2-50 (MAN TGM 18.290), АЦ 3,2-50 (MAN TGM 18.330), АЦ 3,2-50 (MAN TGM 18.340), АЦ 3,2-50/4(MAN TGM 13.250), АЦ 3,2-50/4(MAN TGM 13.280) АЦ 3,2-50/4(MAN TGM 13.290), АЦ 3,2-50/4(MAN TGM 18.280) АЦ 3,2-50/4(MAN TGM 18.290), АЦ 3,2-50/4(MAN TGM 18.330) АЦ 3,2-50/4(MAN TGM 18.340) АЦ 3,2-60 (MAN TGM 13.250), АЦ 3,2-60 (MAN TGM 13.280), АЦ 3,2-60 (MAN TGM 13.290), АЦ 3,2-60 (MAN TGM 18.280), АЦ 3,2-60 (MAN TGM 18.290), АЦ 3,2-60 (MAN TGM 18.330), АЦ 3,2-60 (MAN TGM 18.340), АЦ 3,2-60/4(MAN TGM 13.250), АЦ 3,2-60/4(MAN TGM 13.280) АЦ 3,2-60/4(MAN TGM 13.290), АЦ 3,2-60/4(MAN TGM 18.280) АЦ 3,2-60/4(MAN TGM 18.290), АЦ 3,2-60/4(MAN TGM 18.330) АЦ 3,2-60/4(MAN TGM 18.340) АЦ 3,2-70 (MAN TGM 13.250), АЦ 3,2-70 (MAN TGM 13.280), АЦ 3,2-70 (MAN TGM 13.290), АЦ 3,2-70 (MAN TGM 18.280), АЦ 3,2-70 (MAN TGM 18.290), АЦ 3,2-70 (MAN TGM 18.330), АЦ 3,2-70 (MAN TGM 18.340) АЦ 3,2-100 (MAN TGM 13.250), АЦ 3,2-100 (MAN TGM 13.280) АЦ 3,2-100 (MAN TGM 13.290), АЦ 3,2-100 (MAN TGM 18.280), АЦ 3,2-100 (MAN TGM 18.290), АЦ 3,2-100 (MAN TGM 18.330) АЦ 3,2-100 (MAN TGM 18.340) АЦ 4,0-40 (MAN TGM 13.250), АЦ 4,0-40 (MAN TGM 13.280), АЦ 4,0-40 (MAN TGM 13.290), АЦ 4,0-40 (MAN TGM 18.280), АЦ 4,0-40 (MAN TGM 18.290), АЦ 4,0-40 (MAN TGM 18.330), АЦ 4,0-40 (MAN TGM 18.340), АЦ 4,0-40/4(MAN TGM 13.250), АЦ 4,0-40/4(MAN TGM 13.280) АЦ 4,0-40/4(MAN TGM 13.290), АЦ 4,0-40/4(MAN TGM 18.280) АЦ 4,0-40/4(MAN TGM 18.290), АЦ 4,0-40/4(MAN TGM 18.330) АЦ 4,0-40/4(MAN TGM 18.340) АЦ 4,0-50 (MAN TGM 13.250), АЦ 4,0-50 (MAN TGM 13.280), АЦ 4,0-50 (MAN TGM 13.290), АЦ 4,0-50 (MAN TGM 18.280), АЦ 4,0-50 (MAN TGM 18.290), АЦ 4,0-50 (MAN TGM 18.330), АЦ 4,0-50 (MAN TGM 18.340), АЦ 4,0-50/4(MAN TGM 13.250), АЦ 4,0-50/4(MAN TGM 13.280) АЦ 4,0-50/4(MAN TGM 13.290), АЦ 4,0-50/4(MAN TGM 18.280) АЦ 4,0-50/4(MAN TGM 18.290), АЦ 4,0-50/4(MAN TGM 18.330) АЦ 4,0-50/4(MAN TGM 18.340) АЦ 4,0-60 (MAN TGM 13.250), АЦ 4,0-60 (MAN TGM 13.280), АЦ 4,0-60 (MAN TGM 13.290), АЦ 4,0-60 (MAN TGM 18.280), АЦ 4,0-60 (MAN TGM 18.290), АЦ 4,0-60 (MAN TGM 18.330), АЦ 4,0-60 (MAN TGM 18.340), АЦ 4,0-60/4(MAN TGM 13.250), АЦ 4,0-60/4(MAN TGM 13.280) АЦ 4,0-60/4(MAN TGM 13.290), АЦ 4,0-60/4(MAN TGM 18.280) АЦ 4,0-60/4(MAN TGM 18.290), АЦ 4,0-60/4(MAN TGM 18.330) АЦ 4,0-60/4(MAN TGM 18.340) АЦ 4,0-70 (MAN TGM 13.250), АЦ 4,0-70 (MAN TGM 13.280), АЦ 4,0-70 (MAN TGM 13.290), АЦ 4,0-70 (MAN TGM 18.280), АЦ 4,0-70 (MAN TGM 18.290), АЦ 4,0-70 (MAN TGM 18.330), АЦ 4,0-70 (MAN TGM 18.340) АЦ 4,0-100 (MAN TGM 13.250), АЦ 4,0-100 (MAN TGM 13.280) АЦ 4,0-100 (MAN TGM 13.290), АЦ 4,0-100 (MAN TGM 18.280), АЦ 4,0-100 (MAN TGM 18.290), АЦ 4,0-100 (MAN TGM 18.330) АЦ 4,0-100 (MAN TGM 18.340) АЦ 5,0-40 (MAN TGM 13.250), АЦ 5,0-40 (MAN TGM 13.280), АЦ 5,0-40 (MAN TGM 13.290), АЦ 5,0-40 (MAN TGM 18.280), АЦ 5,0-40 (MAN TGM 18.290), АЦ 5,0-40 (MAN TGM 18.330), АЦ 5,0-40 (MAN TGM 18.340), АЦ 5,0-40/4(MAN TGM 13.250), АЦ 5,0-40/4(MAN TGM 13.280) АЦ 5,0-40/4(MAN TGM 13.290), АЦ 5,0-40/4(MAN TGM 18.280) АЦ 5,0-40/4(MAN TGM 18.290), АЦ 5,0-40/4(MAN TGM 18.330) АЦ 5,0-40/4(MAN TGM 18.340) АЦ 5,0-50 (MAN TGM 13.250), АЦ 5,0-50 (MAN TGM 13.280), АЦ 5,0-50 (MAN TGM 13.290), АЦ 5,0-50 (MAN TGM 18.280), АЦ 5,0-50 (MAN TGM 18.290), АЦ 5,0-50 (MAN TGM 18.330), АЦ 5,0-50 (MAN TGM 18.340), АЦ 5,0-50/4(MAN TGM 13.250), АЦ 5,0-50/4(MAN TGM 13.280) АЦ 5,0-50/4(MAN TGM 13.290), АЦ 5,0-50/4(MAN TGM 18.280) АЦ 5,0-50/4(MAN TGM 18.290), АЦ 5,0-50/4(MAN TGM 18.330) АЦ 5,0-50/4(MAN TGM 18.340) АЦ 5,0-60 (MAN TGM 13.250), АЦ 5,0-60 (MAN TGM 13.280), АЦ 5,0-60 (MAN TGM 13.290), АЦ 5,0-60 (MAN TGM 18.280), АЦ 5,0-60 (MAN TGM 18.290), АЦ 5,0-60 (MAN TGM 18.330), АЦ 5,0-60 (MAN TGM 18.340), АЦ 5,0-60/4(MAN TGM 13.250), АЦ 5,0-60/4(MAN TGM 13.280) АЦ 5,0-60/4(MAN TGM 13.290), АЦ 5,0-60/4(MAN TGM 18.280) АЦ 5,0-60/4(MAN TGM 18.290) АЦ 5,0-60/4(MAN TGM 18.330) АЦ 5,0-60/4(MAN TGM 18.340) АЦ 5,0-70 (MAN TGM 13.250), АЦ 5,0-70 (MAN TGM 13.280), АЦ 5,0-70 (MAN TGM 13.290), АЦ 5,0-70 (MAN TGM 18.280), АЦ 5,0-70 (MAN TGM 18.290), АЦ 5,0-70 (MAN TGM 18.330), АЦ 5,0-70 (MAN TGM 18.340) АЦ 5,0-100 (MAN TGM 13.250), АЦ 5,0-100 (MAN TGM 13.280) АЦ 5,0-100 (MAN TGM 13.290), АЦ 5,0-100 (MAN TGM 18.280) АЦ 5,0-100 (MAN TGM 18.290), АЦ 5,0-100 (MAN TGM 18.330) АЦ 5,0-100 (MAN TGM 18.340); 569915</p>
<p><b>Шасси</b></p>	<p>MAN N08, N16, N18, N26, N28, N34, N36, N37 (TGM 13.250, 13.280, 13.290, 18.280, 18.290, 18.330, 18.340)</p>
<p><b>Экологический класс</b></p>	<p>4 – с двиг. D0836LFL53, D0836LFL54, D0836LFL55, 5 – с двиг. D0836LFL61, D0836LFL62, D0836LFL63, D083</p>
<p><b>Категория транспортного средства</b></p>	<p>N3G</p>

<b>VIN код</b>	VIN с X89569915?0CV8001 по X89569915?0CV8100
<b>Дата выдачи ОТТС</b>	19700101
<b>Дата окончания срока действия ОТТС</b>	19700101